Linking a dealer in VRM

Linking your VRM user account to your dealer allows for better service and support. Once linked, your dealer can access any site you can access, access additional diagnostic information for these sites, and is able to view your contact information.

You can only link to one dealer. Linking a dealer is optional and you can unlink from the dealer at any time.

There are two ways to link a dealer:

1. When registering using a invite from someone who has linked a dealer, you will have the option to link to this dealer as well.
2. When you already have a account, you can link to a dealer by entering their VRM dealer code in your Profile.

You can view your current dealer in your profile. To link a dealer you may fill out their dealer code (which you can request from your dealer), and click the “link” button to link to the corresponding dealer.

You can change your dealer by simply linking to another dealer: fill out their dealer code and click the “change dealer” button. You can also unlink: use the “unlink dealer” button.

From:
https://www.victronenergy.com/live/ - **Victron Energy**

Permanent link:
https://www.victronenergy.com/live/vrm_portal:dealers?rev=1452771399

Last update: **2016-01-14 11:36**