

GX - Fischer Panda generators

Fischer Panda generator can be connected to a GX Device, which makes it possible to monitor & operate the generator as well as automatically start and stop it.

The generator needs to be connected to the VE.Can port of the GX Device, which requires a Fischer Panda SAE J1939 module.

Requirements

- [GX Device](#), with firmware v2.07 or later
- Fischer Panda generator, xControl or iGenerator
- Fischer Panda SAE J1939 CAN module (part number 0006107)
- Fischer Panda FP-Bus to VE.Can adapter (part number 0023441)

Fischer Panda Firmware requirements:

- iControl (for the iGenerator): v2.17 minimum
- iControl panel: no minimum requirement
- xControl (for the constant speed generators): 4V38 minimum
- xContr panel: 4V29
- Fischer Panda SAE J1939 CAN module: 2V05
- Fischer Panda three phase module: 4V0b

Connecting

xControl

The schematic below shows how to connect a Fischer Panda xControl generator.



CAN Interface for xControl and iControl

FP Art. No 0006107

Firmware 2V05 or higher

Modul ID 9

Fischer Panda Generator with
xControl
GC-Modul at generator
Firmware 4V38 or higher
Modul ID 1



Termination
resistor
FP Art. No
0003022

Termination
resistor
FP Art. No
0003022

Adapter cable
FP-BUS - VE.CAN
FP Art. No.
0023441


Victron
Termination
Resistor



Victron device with VE.CAN
f.e. Victron Colour Control

iControl

The schematic below shows how to connect a Fischer Panda iControl generator.



! **Important: Operation of the generator is only possible and allowed when the xControl or the iControl panel is switched on.**

GX Device

In Settings → Services, the selected canbus profile must be one that says NMEA2000. (The default).

When all wiring is complete and the setup has been correctly carried-out, the Fischer Panda will show up in the device list:



Entering the Fischer Panda device on the menu reveals a page like this:

Fischer Panda Genset		13:49
Mode	ON	<input checked="" type="checkbox"/>
Status	Running	
Error Code	#0 No error	
AC	227V	104A
	21.91kW	
Engine		>
Device		>
Pages	Menu	


Notice that it features an on/off switch as well as displaying status information, and the main AC parameters: voltage, current and power.

Engine temperature, RPM and additional information are all available by entering the *Engine* sub menu item.

Engine		14:19
Speed	3000rpm	
Load	42%	
Coolant temperature	64°C	
Exhaust temperature	98°C	
Winding temperature	80°C	
Operating time	12d 16h	
Starter battery voltage	14.7V	
Pages	▲	Menu

Generator start/stop

In addition to the manual start/stop and monitoring, there is also an automatic start/stop feature. This has the same comprehensive range of options as the Generator start/stop feature associated with the GX relay. See [generator_start_stop](#) for the manual.




Maintenance

Whenever performing maintenance on the generator, be sure to *stop* the generator from the Fischer Panda control panel. This will disable the Fischer Panda autostart feature, and ensures that the generator cannot be remotely started - by a CCGX, for example.

When the maintenance is completed, make sure you enable the autostart feature again. You can do this on the Fischer Panda control panel in the menu generator → autostart → turn on / off.

MFD App

The Marine MFD HTML5 app (more information [here](#)) also contains an element which allows monitoring as well as control of the Fischer Panda generator:




Troubleshooting

I've set the mode of the genset to 'On' or 'Auto start/stop' but the generator is not starting/running.

Make sure the Fischer Panda autostart feature is on, this allows the GX control the remote on/off of

the genset. You can find this option on the control panel in the menu generator → autostart → turn on / off.

If you're manually trying to start the genset, a toast message appears with the text AutoStart functionality is currently disabled, enable it on the genset panel in order to start the genset from this menu.



If the generator auto start/stop is enabled, it will show error #1 Remote switch control



disabled on the Auto start/stop page.

From:

<https://www.victronenergy.com/live/> - **Victron Energy**

Permanent link:

https://www.victronenergy.com/live/ccgx:fischer_panda?rev=1599474588

Last update: **2020-09-07 12:29**

