2025-11-11 16:19 1/1 How to update an Assistant

How to update an Assistant

When started, and connected to the internet, VEConfigure3 will automatically download the latest versions of Assistants. Below procedure explains how to connect to already configured products and update the Assistant to the latest version.

Subscribe to our blog to receive an email update about new and updated Assistants.

Procedure

- 1. First download the latest Assistants from internet:
 - 1. Make sure your computer is connected to the internet
 - 2. Start VEConfigure3
 - 3. It will give a notification when new Assistants are available
- 2. Connect VEConfigure 3 to the system, it will read all the settings
- 3. A warning will appear, explaining that there is a new version of one or more of the configured Assistants.[plaatje invoegen]
- 4. All Assistants that can be updated will be in italic and marked with a star.
- 5. Right click the assistant, and press update [plaatje sturen]
- 6. VEConfigure will guide you through all the pages in the Assistant: verify the values, the settings are the same as you have configured originally. Click next until finished.
- 7. Click send settings and include the Assistants. Note: the system will momentarily switch off!
- 8. All done.

From

https://www.victronenergy.com/live/ - Victron Energy

Permanent link:

https://www.victronenergy.com/live/assistants:how_to_update_an_assistant?rev=1408131699

Last update: 2014-08-15 21:41

