

MPPT FAQ

75/15 and 100/15 cannot be controlled by a BMS, what now?

The reason is that the RX pin is already used to the battery life on/off selection with the jumper. So therefore it is unfortunately not possible to control these two models with the VE.Direct .. remote on/off cable [link]. The solution is buy the next model in line: the MPPT 100/30.

Can the output of the MPPT be used as a power supply, thus without batteries?

The answer is; it depends on the type of load.

During low current situations the MPPT control bandwidth is too small to be able to maintain a stable voltage. The result is that loads that need to see a stable voltage before they can activate or loads that require a certain “under voltage” to activate will not be able to run.

Loads where under voltage does not apply, like light globes, can be operated without any problems.

I want to over dimension the PV array, how can I calculate the maximum?

There are only two limits, when determining the maximum array size that can be connected to an MPPT:

1. The Maximum PV open circuit voltage
2. The Maximum PV short circuit current

Both values are specified in the datasheets of all our MPPT Solar Chargers

Note that you cannot multiply these values to determine the installable maximum Wp. Instead, look on the datasheets of the solar panels, to see what their max PV short circuit current is.

And same for the Maximum PV open circuit voltage, and then do not forget to take the coldest expected temperature into account. Because the colder it is, the higher the max voltage.

DISQUS Comments

~~DISQUS~~

From:
<https://www.victronenergy.com/live/> - **Victron Energy**



Permanent link:
https://www.victronenergy.com/live/drafts:mppt_faq?rev=1480603821

Last update: **2016-12-01 15:50**