# **Furuno MFD Integration**

## 1. Introduction

This document explains how to connect to Furuno MFDs using an Ethernet connection.

Make sure to also study the Marine MFD Integration by App chapter in the manual.

Note that there is an alternative method to connect, which is NMEA2000. See the NMEA2000 chapter in the main manual. Currently Furuno MFDs only have support for fluid level PGNs sent out by Victron equipment.

### 2. Compatibility

The MFD integration is compatible with the following Furuno MFDs:

- NavNet TZtouch3 TZT12F
- NavNet TZtouch3 TZT16F
- NavNet TZtouch3 TZT19F
- Navnet TZtouch2 TZT2BB Black box
- NavNet TZtouchXL TZT22X
- NavNet TZtouchXL TZT24X

NavNet TZtouch3 MFDs need at least software version v1.08. The Navnet TZtouch2 TZT2BB needs at least software version v7.01.

Note that the Navnet TZtouch2 TZTL models are **not** supported.

From Victron side, all GX devices (Cerbo GX, CCGX, Venus GX, and so forth) can be used and are compatible. For details on detailed product compatibility with regarding to inverter/chargers and other components, see the main Marine MFD App chapter in the GX Manual.

### 3. Wiring

The Furuno device needs to be connected to the GX device using Ethernet. Its not possible to connect over WiFi. For the Ethernet connection, a standard Ethernet cable can be used. The GX device can either be connected directly to the MFD or through a network router/switch.

### 4. Configuration

#### 4.1 Ethernet configuration

On the Victron GX Device, make sure that the Ethernet cable is connected and go to Settings  $\rightarrow$ 

*Ethernet*, and set the following configuration:

Setting	Value
IP Configuration	Manual
IP address	172.31.201.12
Netmask	255.255.0.0
Gateway	0.0.0.0 or the IP address of the router in your network
DNS server	0.0.0.0 or the IP address of the router in your network

<	Ethernet	<b>\earlimetry</b> 11:10
IP configuration		Manual
IP address		172.31.201.12
Netmask		255.255.0.0
Gateway		
DNS server		
Link-local IP address		169.254.9.175
<u>.ı.l</u> Pages	~	<b>≣</b> Menu

It is possible to connect a router to the same LAN; and that way connect the GX Device to the internet. Make sure the *Gateway* and *DNS Server* settings of the GX are set to the IP address of the router, and that the router has its LAN IP addressing configured in the same subnet.

It is not possible to use a GX GSM.

### 4.2 Services configuration

On the Victron GX Device, go to Settings  $\rightarrow$  Services, and there enable both MQTT on LAN (SSL) and

<	Services	10:54
Modbus TCP		Disabled >
MQTT on LAN (SSL)		
MQTT on LAN (Plainte	ext)	$\bigcirc$
VRM two-way commu	unication	
CAN-bus		>
Pages <u>الا</u>		<b>≣</b> Menu

MQTT on LAN (Plaintext).

Next, go to Menu  $\rightarrow$  Settings  $\rightarrow$  System Setup  $\rightarrow$  Battery Measurements. And there set up what batteries you want to see on the MFD; and by what name.

<	Marine MFD App configu	ration 10:49
Hydraulic ba	ttery	Visible >
Hydraulic ba	ttery (Auxiliary measurem	Hidden >
House batter	ry	Hidden >
MultiPlus 48/	/3000/35-50	Hidden >
Pa اس	ges	<b>≣</b> Menu
<	Hydraulic battery	10:51
<b>&lt;</b> Visible	Hydraulic battery	10:51 ive battery monitor
< Visible Name	Hydraulic battery Act	10:51 ive battery monitor Hydraulic battery
< Visible Name	Hydraulic battery	10:51 ive battery monitor Hydraulic battery

### 5. Configuring Multiple Battery Monitors



Video

### 6. NMEA 2000

The MFD can also be connected to the Victron system using NMEA 2000, see the NMEA 2000 & MFD integration guide.

This chapter documents the specifics when displaying Victron NMEA 2000 information on a Furuno MFDs. Note that this is not meant to be an extensive guide. Its the simple result of our R&D checking everything on a Furuno MFD. The functionality is (mostly) dictated by Furuno software and may therefore also change and improve when Furuno company changes their software.

The MFD can be configured easily to display the data from the GX device. To display tank data, there is no need to change any instance.

In order to properly display battery/DC data from Victron equipment, you need to change the data instances of the PGNs that are sent out. See here for how to do that: Changing NMEA2000 Instances, section Data instances.

To view NMEA 2000 devices on the MFD, go to *Settings* > *Initial Setup* > *Data Aquisition* > *Sensor List*. Here you can view basic information and change device instances and custom names.

The following Victron PGNs are supported:

- 127505 Fluid level (tanks)
- 127506 DC Detailed Status (limited support); State-of-charge, Time-to-go (1)
- 127508 Battery Status (limited support); Voltage, Current (1, 2)

#### Notes

- 1. The tested Furuno MFD firmware supports a maximum of 4 batteries, no more
- 2. Due to a bug in the MFD firmware, a negative battery current (ie. when discharging) is shown as - - - (three dashes)

From: https://www.victronenergy.com/live/ - Victron Energy

Permanent link: https://www.victronenergy.com/live/venus-os:mfd-furuno?rev=1681384580



Last update: 2023-04-13 13:16