

VE.Can to CAN-bus BMS cables manual

Use these [VE.Can to CAN-bus cables](#) to connect a CAN-bus enabled battery to a [GX device](#).

1. Selecting the right cable

ASS030710018 - VE.Can to CAN-bus BMS type A Cable 1.8m

- BYD B-Box
- Hubble Lithium via CloudLink (AM-10+/Blade internal CloudLink)
- Pylontech US2000C/US3000C/UP5000/Force-L

ASS030720018 - VE.Can to CAN-bus BMS type B Cable 1.8m

- AXIstorage 7S/9S
- BMZ
- BSLBATT Lithium battery
- Hubble AM-2/4/5/10, X101 (No CloudLink)
- LG Chem Resu
- Pylontech US2000/US3000/UP2500
- Solar MD BMS EX
- Freedom Won eTower

ASS030064950 RJ45 UTP Cable (Standard Ethernet)

- Bluenova Energy Storage
- Cegasa eBick
- Freedom Won LiTE
- MG Energy Systems

Custom (See Battery Documentation)

- Exide
- SolarMD Logger V2

2. Installation

The side labeled 'CAN-bus BMS' plugs into the battery. The other side, labeled 'VE.Can' must be plugged into either the VE.Can port of the GX device, or the BMS-Can port.

Both port types (VE.Can and BMS-Can) on a GX Device can be configured for use with a CAN-bus BMS connected third party battery.

For configuration, see the manual specific to the brand of battery you are using.

3. Pin-out

In some cases it might be needed to make the cable at the location. Find below the pin-outs. Make sure to very carefully test the cable after crimping it. Self-made cables are very often the causes of very hard to diagnose problems.

3.1 Type A

Function	Victron VE.Can side	Battery side
GND	Pin 3	Pin 6
CAN-L	Pin 8	Pin 5
CAN-H	Pin 7	Pin 4

3.2 Type B

Function	Victron VE.Can side	Battery side
GND	Pin 3	Pin 2
CAN-L	Pin 8	Pin 5
CAN-H	Pin 7	Pin 4

From: <https://www.victronenergy.com/live/> - **Victron Energy**

Permanent link: https://www.victronenergy.com/live/battery_compatibility:can-bus_bms-cable?rev=1739945330

Last update: **2025-02-19 07:08**

