Updating VE.Bus firmware, using VEFlash

Notes

- To update a VE.bus product, (Inverters, Multis and Quattros), you need VEFlash.exe. It comes with the VE Configure Tools, available for download on our software page
- Always use the latest version of VEFlash. It will automatically check online for updates on startup
- When updating parallel or three-phase installation, update each unit separately
- After updating firmware, all settings will be reset to defaults. The unit will be reset to stand alone mode and any Assistant settings will be removed.
- There are different firmware types available, read our PDF VE.Bus firmware versions explained carefully to select the best firmware for your system.
- When requesting firmware for a VE.Bus product, always include the current firmware version. This will be a seven digit number, starting with 19, 20, 26 or 27. For example 1926154. Make sure to include the purpose of the update, so we can help selecting the right firmware type and version.

Step by step instructions

Follow steps on screen

Victron Firmware Flasher			
Welcome			
This program can be used to update the firmware of your Victron device. Some devices can also be upgraded.			
Press Start to continue.			
version 90.05.134			
Check for update at startup			
X Cancel			



Save Firmware file in an easy folder to find



Victron Firmware Flash	er		
Select f	ïle		((Q))
Please enter the new firmwar	e name of the file which e.	i cont	tains
C:\Users\Vesa Ar	ndre\Desktop\1941203.vff		B <u>r</u> owse
🗙 Cancel	< Back		Next >



Follow these steps carefully

Victron Firmware Flashe	r	
Connec	t part 1	((Q))
1. Switch off de∨ 2. Disconnect m 3. Connect the c and the PC.	ice. ains power (only fo ommunication cabl	r Multi Compact). e to the device
🗙 Cancel	< Back	Next >







Once finished and OK is selected the Inverter/charger will reset itself.



Note that all settings will be reset to defaults. Also, the unit will be reset to stand alone mode and any Assistant settings will be removed.

~~DISQUS~~

