2025-11-10 10:18 1/1 Integrating with SolarEdge

GX SolarEdge Manual

1. Introduction

You can connect your GX Device with a SolarEdge PV solution, using the ModbusTCP Sunspec protocol. Sunspec is an industry standard protocol for exchanging PV Inverter yield information.

- Zero Feed-in for SolarEdge is not available when used with a Victron System,
- Frequency shift power control, as required in a AC-Coupling system might work, but has not been tested.

With those limitations, it is possible for the SolarEdge to be used in ESS systems where feed-in to the grid is allowed, but only when connecting the SolarEdge to the AC-input of the Victron inverter/charger. In other sorts of systems, for example Off-grid systems, or ESS systems in areas where grid feed-in is not allowed, using a SolarEdge PV solution is not supported by Victron.

2. How to configure

- 1. Ensure that the GX Device and the SolarEdge system are both on the same LAN or WiFi network.
- 2. Enable ModbusTCP support on your SolarEdge system. Consult the SolarEdge documentation for that.
- 3. On the GX Device, navigate to Settings → PV Inverters. Search for the Solar Edge and complete the configuration.

Details:

- 1. The SE2200H SE6000H range (HD-wave) was specifically tested, though several others are reported to work too.
- 2. The Modbus id has to be set at 126. This is done in the SE inverter menu, configuration, RS485-1 menu. Although this is in the RS485 menu it also sets the ID for modbus over TCP-IP
- 3. During testing, we found that the SolarEdge PV Inverter accepts just one concurrent TCP connection. Additional connections are rejected.

From:

https://www.victronenergy.com/live/ - Victron Energy

Permanent link:

https://www.victronenergy.com/live/venus-os:gx solaredge?rev=1558875928

Last update: **2019-05-26 15:05**

